




MT Series

SINGLE RANGE MODELS

-Including MTC Type-

Service Manual



ISHIDA CO., LTD.

Table of Contents

■ 1 Introduction

1.1 EXTERNAL VIEW	1-1
1.2 FEATURES	1-5
1.3 SPECIFICATIONS	1-5
1.4 EXTERNAL DIMENSIONS	1-6

■ 2 Registration

2.1 OVERVIEW	2-1
2.2 CONSOLE LAYOUT	2-1
2.3 TEST MODE	2-2

■ 3 Mechanical Components

3.1 OVERVIEW	3-1
3.2 SCALE UNIT	3-1
3.3 CONSOLE UNIT EXPLODED VIEW	3-3
3.4 CPU BOARD P-660 REPLACEMENT	3-5
3.5 LOAD CELL REPLACEMENT	3-6
3.6 CONSOLE ANGLE ADJUSTMENT	3-7

■ 4 Electrical Components

4.1 ELECTRICAL SYSTEM CONFIGURATION	4-1
4.2 LOAD CELL SPECIFICATIONS	4-2
4.3 CPU BOARD P-660	4-2

■ 5 Optional Equipment

5.1 OVERVIEW	5-1
5.2 INSTALLATION PROCEDURE	5-1
5.3 HOW TO LOAD RECEIPT PAPER	5-2
5.4 JOURNAL PRINTER UNIT	5-2
5.5 MAINTENANCE	5-3
5.6 PRINTOUT SAMPLE	5-4

■ 6 Installation for Customer

6.1 INSTALLATION PROCEDURE	6-1
6.2 CAUTIONARY INSTRUCTIONS	6-1

■ 7 Troubleshooting

7.1 MAIN COMPONENTS	7-1
7.2 TROUBLESHOOTING GUIDE	7-2

■ 8 Schematics

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/ishida/MT service manual.html](https://the-checkout-tech.com/manuals/ishida/MT%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)