



MTE Series

Bench Scale

Service Manual




Table of Contents

1 Introduction

1.1	STANDARD SPECIFICATION	1-1
1.2	ELECTRONIC CONFIGURATION	1-2
1.3	CONNECTOR	1-4
1.4	DISPLAY PANEL	1-6

2 Weighing Mode

2.1	POWER ON	2-1
2.2	ZERO ADJUSTMENT	2-1
2.3	TARE SETTING	2-1
2.4	CHECK FUNCTION	2-3
2.5	LB/KG MODE SWITCHING	2-4
2.6	HOLD FUNCTION	2-4

3 Registration

3.1	SPAN ADJUSTMENT	3-1
3.2	C1 MODE	3-5
3.3	C2 MODE	3-7
3.4	C3 MODE	3-8
3.5	L MODE	3-8
3.6	G MODE	3-8
3.7	DATA CLEAR	3-9

4 Parts Replacement

4.1	PRECAUTIONS BEFORE SERVICING	4-1
4.2	ERROR MESSAGE	4-1
4.3	TROUBLESHOOTING	4-2

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/ishida/MTE service manual.html](https://the-checkout-tech.com/manuals/ishida/MTE%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)