



SERVICE MANUAL JCL

Contents

1. Assembly Drawing	
1-1 Explosive view.....	1
1-2 Part list.....	1
2. Electronic Construction	
2-1 Block diagram.....	2
2-2 PCB board wiring.....	3
2-3 Power circuit diagram.....	4
3. RS-232 Communication	
3-1 RS-232 connector.....	5
3-2 RS-232 circuit diagram.....	5
3-3 Single option.....	6
3-4 Two options.....	9
3-5 Time setting.....	10
3-6 RS-232 output format.....	11
4. Adjustments and Settings	
4-1 Model setting.....	12
4-2 Single point calibration.....	12
4-3 Linear calibration.....	12
4-4 Function setting	13
4-5 Scale initialization.....	15
4-6 Set division.....	15
4-7 Offset value display and key test.....	15
5. Trouble Shootings	
5-1 Primary checks.....	15
5-2 Problems and solutions.....	16
5-3 Error message.....	18
6. Parts Replacement	
6-1 Main board replacement	19
6-2 Loadcell replacement.....	21
6-3 Rechargeable battery replacement	23
6-4 RS-232 replacement.....	24
6-5 Keypad replacement.....	25
6-6 LCD replacement.....	26
7. Unit Switch Operation.....	27
8. Applicable Version and Software.....	27

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*