JADEVER JKD Service Manual

Chapter I Brief Introduction	
1-1 Dimension	2
1-2 Power Supply Voltage	2
Chapter II Setting	
2-1 Setting Adjustment	3
2-2 Offset Value and Compensation Method	3
2-3 Calibration Procedures	3
Chapter III Disassembly and Assembly Procedures	
3-1 JKD PCB and Load Cell Replacement Procedures	4
Chapter IV Troubleshooting	
4-1 Preliminary Examination	
4-2 Test Points – Working Signals	7
4-3 Troubleshooting	8
4-4 Load Cell Related Technology	9

This is a "Table of Contents preview" for quality assurance

The full manual can be found at <a href="http://the-checkout-tech.com/estore/catalog/">http://the-checkout-tech.com/estore/catalog/</a>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<u>http://the-checkout-tech.com</u>: the biggest supplier of cash register and scale manuals on the net