

Chapter I Basic Introduction

1-1 Dimension-----	1
1-2 Cross-reference List of Characters-----	1
1-3 Product Specification Sheet-----	2

Chapter II Parameter Function Setting

2-1 General Parameter Setting-----	3
2-2 Advanced Parameter Setting-----	5
2-3 Weighing Capacity, Sensed Weight Setting and Weight Calibration-----	7

Chapter III Various Assemblies and Relevant Illustrations

3-1 Back Cover Assembly and Disassembly-----	9
3-2 Installation of Additional Board-----	10
3-3 Wiring Cross-reference Chart-----	11
3-4 Illustration of Contacts of Additional Board-----	12

Chapter IV Troubleshooting

4-1 Preliminary Examination-----	13
4-2 Error Message and Troubleshooting-----	13
4-3 Summary Table of Error Message-----	16

Chapter V Structural Part of Platform Scale

5-1 Connection of Metal Connectors-----	17
5-2 L/C Replacement Process-----	17
5-3 L/C-related Technology-----	19

Chapter VI Exploded Drawing and Cross-reference List of Parts

6-1 JIK 6-CAB -----	20
6-2 JIK 6-CSB -----	21
6-3 JIK 6-CSN -----	22

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*