

## USER'S MANUAL      JKD 50/100/250/500

### Step before Operation:

- Remove protective coating on batteries
- Remove the screw. The screw locates on the top left when you open the battery cover.



### Precautions:

1. Make sure the protect plastic cover is open before switch on the scale.
2. Due to this is a high precision scale, please use the product in stable and leveling circumstances.
3. Please don't operate under severely changeable temperature (Normal 0°C -40°C)
4. Avoid wind blowing places & nearby vibrating equipment
5. Strike-resist strength for the plastic protect cover is 45kgf / cm<sup>2</sup>

### Features:

- Resolution 1/5000  
( internal resolution 1/15000 )
- g / oz / ct / pcs or g/ dwt/ ozt/ pcs
- Simple and convenient counting function
- Auto shut off after not be operated in 4 minutes
- Net/Gross weight

Battery life over 120 hours

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/jadever/JKD-50 JDK-100 JDK-250 JDK-500 user>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)