

JWL Series

Weighing Scale

User Manual

JADEVER

<http://www.jadever.com>

CONTENTS

1. Introduction	1
2. Precautions	1
3. Before Using the Product	
3-1 Unpacking and Checking.....	1
3-2 Installing Components	1
3-3 Leveling the Scale.....	1
4. Product Introduction	
4-1 Specifications & General Features	2
4-2 Display	3
4-3 Keyboard.....	4
4-4 Power Supply.....	4
5. Operation	
5-1 Weighing.....	5
5-2 Manual Tare & Preset Tare	5
5-3 Check weighing	6
5-4 Simple Counting.....	6
5-5 Accumulation, Accumulation Display and Accumulation Clearing.....	7
5-6 Unit Setting Menu.....	7
6. Calibration	
6-1 Single Point Calibration	8
6-2 Linear Calibration.....	8
7. Setting Mode & Description of Parameter Values	9
Serial Interface	
8-1 RS-232 Connector.....	11
8-2 Single Option.....	11
Troubleshooting and Error Message	11

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/jadever/JWL user and calibration manual.html](https://the-checkout-tech.com/manuals/jadever/JWL_user_and_calibration_manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)