

JWP ***Series***

Service Manual

SECTION 1.	Structure assembly drawing	2
1-1	Breakdown drawing of whole scale set (fixed pan type)	2
1-2	Breakdown drawing of whole scale set (movable pan type)	3
1-3	Breakdown drawing of scale body	4
1-4	Breakdown drawing of platform	5
1-5	Breakdown drawing of upper case	6
1-6	Breakdown drawing of base	7
1-7	Breakdown drawing of load cell components	8
1-8	Breakdown drawing of front display board	9
1-9	Breakdown drawing of rear display board	10
1-10	Spare part list	11
SECTION 2.	Electronic structure	13
2-1	Block diagram	13
2-2	Wring diagram	14
SECTION 3.	Steps of troubleshooting	14
3-1	Table of troubleshooting	14
3-2	Confirmation of application environments	15
SECTION 4.	Service and setting	15
4-1	Flows of service	15
4-2	Calibration method and model setting	17
4-3	Parameter and function setting	18
4-4	Switch of accuracy	21

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*