

LAC LGC

USER'S MANUAL

COUNTING SCALE

CONTENTS

INSTALLATION	1
UNLOCK LOAD CELL PROTECTION	2
TURN ON SCALE	3
BATTERY STATUS INDICATION.....	3
RECHARGING BATTERY.....	3
CALIBRATION	4
KEYBOARD TEST AND OFFSET VALUE CHECK	5
POWER ON SETUP	6
CAPACITY-RESOLUTION SETUP	6
DIGITAL FILTERING	7
AUTO POWER-OFF	8
ZERO BAND	8
BACKLIGHT	8
ZERO	9
TARE	9
UNIT WEIGHT SETTING	10
UNIT WEIGHT BY SAMPLING	10
COUNTING CHECK	11
ACCUMULATION (For LAC only)	11
ACCUMULATE DATA	11
RECALL DATA	12
CLEAR DATA	12

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/jadever/LAC and LGC users and calibration man](https://the-checkout-tech.com/manuals/jadever/LAC%20and%20LGC%20users%20and%20calibration%20man)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)