

OPERATION

1. Turn the power switch to the ON position.

2. Press the ON/OFF key.

3. Press the TARE key.

When measuring:

1. Place the object to be weighed on the weighing pan.

2. Turn the power switch to the ON position.

3. Press the TARE key.

4. Put on the weighing pan.

When measuring:

PW/GW Series
Weighing Scale
Service Manual

Note: Manual is 13 pages long, including circuit diagrams

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/jadever/PW> and [GW service and calibration man](#)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)