



**Model 7820 B  
UPS Revenue Recovery Scale  
User's Manual**

# Table of Contents

NCI Model 7820 B Specifications .....	4
Unpacking Your Scale .....	5
Weights And Measures Sealing.....	5
Battery Operation .....	5
Charging The Battery .....	5
Battery Replacement.....	5
Operation .....	6
Keys .....	6
Sleep / Auto Shutdown Modes .....	6
Backlight Operation .....	7
Weight Hold Operation .....	7
Changing the Backlight Settings.....	8
Changing the Weight Hold Settings .....	9
Weight Hold – Weights And Measures Sealing .....	9
Cleaning And Care .....	10
Warranty & Service .....	10
Service Replacement Parts .....	10

## NCI Model 7820 B Specifications

<b>Construction:</b>	Die Cast aluminum load bridge and base, stainless steel weight platter, aluminum display handle
<b>Capacity:</b>	0 – 200lb x 0.05lb or 0 – 100kg x 0.02kg
<b>Accuracy:</b>	+/- 1 division (0.05lb / 0.02kg)
<b>Display:</b>	6-digit backlight LCD, in extruded aluminum housing w/ 7-foot off the shelf CAT-5 cable
<b>Display Size:</b>	6" L x 3" D x 1½" H
<b>Platter Size:</b>	14" L x 12½" D
<b>Power Supply:</b>	Input 120 VAC 60 Hz, Output 14VDC 750mA
<b>Battery:</b>	12 VDC / 1.3AH Sealed Lead Acid Battery

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/NCI/7820B users manual.html](https://the-checkout-tech.com/manuals/NCI/7820B%20users%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)