




Operator Manual

OHAUS Aviator 7000



Contents

1	Your new retail scale	5
1.1	Most important functions	5
1.2	Device overview	5
1.3	Safety instructions	8
1.4	Calibration instructions	8
2	Setting up	9
2.1	Scope of delivery	9
2.2	Requirements for scale's location	9
2.3	Setting up the scale	9
2.4	Inserting the batteries	10
2.5	Connecting to mains power	11
2.6	Turning scale on/off	11
2.7	Cleaning	11
3	Operation	12
3.1	Free input	12
3.2	Working with PLUs	12
3.3	Using tare	16
3.4	Zeroing	17
3.5	By-count operation	17
3.6	Accumulating	18
3.7	Change function	19
3.8	Fix unit price and/or tare	20
3.9	Hold function	21
3.10	Weighing with 100 g (1/2 lb / 1/4 lb) price unit	21
3.11	Switching weighing unit between kg and lb	22
3.12	Displaying the price to pay in EURO	22
3.13	Backlight function	22
3.14	Ticket printing	23
3.15	Printing reports	25
4	Operator setup	27
4.1	Setup operation	27
4.2	Operator setup overview	28
4.3	Setting date and time	31

5	What do you do if...?	32
6	Technical data and accessories	33
6.1	Technical data	33
6.2	Accessories	33
7	Appendix	34
7.1	Disposal	34

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/ohaus/Aviator 7000 operating manual.html](https://the-checkout-tech.com/manuals/ohaus/Aviator%207000%20operating%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)