



Explorer *Pro* Instruction Manual




TABLE OF CONTENTS

1.	INTRODUCTION	EN-3
1.1	Description	EN-3
1.2	Features	EN-3
1.3	Safety Precautions	EN-3
2.	INSTALLATION	EN-3
2.1	Unpacking	EN-3
2.2	Installing Components	EN-4
2.2.1	Platform Installation	EN-4
2.2.2	Windshield Installation	EN-4
2.2.3	Weigh Below Preparation	EN-4
2.3.	Selecting the Location	EN-5
2.3.1	Balance Location	EN-5
2.3.2	Leveling the Balance	EN-5
2.4	Connecting Power and Communications	EN-6
2.4.1	AC Adapter Installation	EN-6
2.4.2	RS232 Interface	EN-6
2.4.3	Initial Calibration	EN-7
3.	OPERATION	EN-8
3.1	Overview of Controls	EN-8
3.2	Overview of Display Indicator	EN-10
3.3	Menu	EN-11
3.3.1	Menu Structure	EN-11
3.3.2	Navigation	EN-11
3.3.3	Turning On the Balance	EN-11
3.4	Applications	EN-12
3.4.1	Weighing	EN-12
3.4.2	Parts Counting	EN-13
3.4.3	Percent Weighing	EN-17
3.4.4	Animal Weighing	EN-19
3.4.5	Check Weighing	EN-20
3.4.6	Gross/Net/Tare Weighing	EN-21
3.4.7	Filling	EN-22
3.5	Balance Settings	EN-23
3.5.1	Calibration	EN-23
3.5.2	Balance Options	EN-24
3.5.3	Readout	EN-25
3.5.4	Application Modes	EN-26
3.5.5	Units	EN-26

TABLE OF CONTENTS (Cont.)

3.5.6	Interface	EN-27
3.5.7	Print Options	EN-28
3.5.8	GLP Print Options	EN-28
3.5.9	Lockout	EN-29
3.5.10	Factory reset	EN-29
3.9.11	LFT Legal for Trade	EN-30
3.5.12	Hardware Lock Switch	EN-30
3.5.13	Sealing the Balance	EN-30
3.6	Printing Data	EN-30
4.	CARE AND MAINTENANCE	EN-31
4.1	Cleaning	EN-31
4.2	Troubleshooting	EN-31
4.3	Error Codes List	EN-32
4.4	Service Information	EN-33
4.5	Replacement Parts	EN-33
4.6	Accessories	EN-33
5.	TECHNICAL DATA	EN-34
5.1	RS232 Commands	EN-34
5.2	Specifications	EN-35

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*