



RA Series Price Computing Scale



1.	INTRODUCTION.....	2
2.	INSTALLATION	2
2.1	Unpacking.....	2
2.2	Assembling	2
2.3	Selecting the Location	3
2.4	Leveling the Scale	3
2.5	Connecting Power	3
3.	OVERVIEW OF CONTROLS AND FUNCTIONS.....	4
3.1	Control Panel.....	4
3.2	Customer Display.....	4
3.3	Keys and Display Indicators	5
4.	OPERATIONS.....	6
4.1	Turning the Unit On and Off.....	6
4.2	Zero Operation	6
4.3	Manual Tare	6
4.4	Keyboard Tare	6
4.5	Clearing Tare	6
4.6	Weighing and Pricing	6
4.7	PLU Function (Price Lookup)	7
4.8	By-Count Function.....	7
4.9	Accumulation Function.....	8
4.10	Backlight Feature.....	8
4.11	Battery Power Saving Feature.....	8
5.	SCALE SETTINGS.....	10
5.1	Accessing the User Setup Mode.....	10
5.2	User Setup Parameters.....	10
6.	CALIBRATION AND SEALING	11
6.1	Calibration.....	11
6.2	Type Approval Sealing	13
7.	MAINTENANCE.....	13
7.1	Cleaning	13
7.2	Troubleshooting	14
8.	TECHNICAL DATA	15
8.1	Specifications	15
8.2	Drawings	16
8.3	Compliance	16
	LIMITED WARRANTY	18

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*