



## *RE Series Price Computing Scale*



*RE-C (with Tower) Model*



*RE Model*

---

1.	INTRODUCTION.....	2
2.	INSTALLATION .....	2
2.1	Unpacking .....	2
2.2	Assembling.....	2
2.3	Selecting the Location.....	3
2.4	Leveling the Scale.....	3
2.5	Connecting Power.....	3
3.	OVERVIEW OF CONTROLS AND FUNCTIONS.....	5
3.1	Control Panel .....	5
3.2	Customer Display .....	5
3.3	Keys and Display Indicators.....	6
4.	OPERATIONS.....	7
4.1	Turning the Unit On and Off.....	7
4.2	Backlight Operation.....	7
4.3	Zero Operation.....	7
4.4	Manual (Pushbutton) Tare.....	7
4.5	Pre-set (Keyboard) Tare .....	7
4.6	Weighing and Pricing .....	8
4.7	Hold Function.....	8
4.8	Pre-pack Weighing Function .....	8
4.9	PLU Function (Price Lookup).....	9
4.10	By-Count Function .....	10
4.11	Accumulation (Totalize) Function.....	10
4.12	Fractional Pricing.....	11
5.	SCALE SETTINGS.....	12
5.1	Accessing the User Setup Mode .....	12
5.2	User Setup Parameters .....	12
6.	CALIBRATION AND SEALING .....	13
6.1	Calibration .....	13
6.2	Type Approval Sealing.....	15
7.	TROUBLESHOOTING .....	16
7.1	Cleaning.....	16
7.2	Troubleshooting.....	17
8.	TECHNICAL DATA .....	18
8.1	Specifications.....	18
8.2	Drawings.....	19
8.3	Compliance .....	20
	LIMITED WARRANTY .....	21

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/ohaus/RE and RE-C instruction manual.html](https://the-checkout-tech.com/manuals/ohaus/RE%20and%20RE-C%20instruction%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)