



RE Series Price Computing Scale



RE-C (with Tower) Model



RE Model

| | | |
|------|---|----|
| 1. | INTRODUCTION..... | 2 |
| 2. | INSTALLATION | 2 |
| 2.1 | Unpacking | 2 |
| 2.2 | Assembling..... | 2 |
| 2.3 | Selecting the Location..... | 3 |
| 2.4 | Leveling the Scale..... | 3 |
| 2.5 | Connecting Power..... | 3 |
| 3. | OVERVIEW OF CONTROLS AND FUNCTIONS..... | 5 |
| 3.1 | Control Panel | 5 |
| 3.2 | Customer Display | 5 |
| 3.3 | Keys and Display Indicators..... | 6 |
| 4. | OPERATIONS..... | 7 |
| 4.1 | Turning the Unit On and Off..... | 7 |
| 4.2 | Backlight Operation..... | 7 |
| 4.3 | Zero Operation..... | 7 |
| 4.4 | Manual (Pushbutton) Tare..... | 7 |
| 4.5 | Pre-set (Keyboard) Tare | 7 |
| 4.6 | Weighing and Pricing | 8 |
| 4.7 | Hold Function..... | 8 |
| 4.8 | Pre-pack Weighing Function | 8 |
| 4.9 | PLU Function (Price Lookup)..... | 9 |
| 4.10 | By-Count Function | 10 |
| 4.11 | Accumulation (Totalize) Function..... | 10 |
| 4.12 | Fractional Pricing..... | 11 |
| 5. | SCALE SETTINGS..... | 12 |
| 5.1 | Accessing the User Setup Mode | 12 |
| 5.2 | User Setup Parameters | 12 |
| 6. | CALIBRATION AND SEALING | 13 |
| 6.1 | Calibration | 13 |
| 6.2 | Type Approval Sealing..... | 15 |
| 7. | TROUBLESHOOTING | 16 |
| 7.1 | Cleaning..... | 16 |
| 7.2 | Troubleshooting..... | 17 |
| 8. | TECHNICAL DATA | 18 |
| 8.1 | Specifications..... | 18 |
| 8.2 | Drawings..... | 19 |
| 8.3 | Compliance | 20 |
| | LIMITED WARRANTY | 21 |

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*