

TABLE OF CONTENTS

- 1. INTRODUCTION EN-3
 - Safety Precautions EN-3

- 2. INSTALLATION EN-3
 - Unpacking EN-3
 - Installing Components EN-4
 - Releasing the Shipping Lock EN-4
 - Platform Installation EN-4
 - Security Bracket EN-4
 - Selecting the Location EN-4
 - Balances with Level Adjustment EN-4
 - Connecting Power EN-5
 - Battery Installation EN-5
 - AC Adapter Installation EN-5

- 3. OPERATION EN-5
 - Overview of Controls and Display Functions EN-5
 - Button Functions EN-7
 - Symbols Used for Operation of the Balance EN-8
 - Turning the Balance On EN-8
 - Turning the Balance OFF EN-8
 - Navigating the Menus EN-9
 - Menu Structure EN-9
 - Entering the Menus EN-10
 - Accepting/Bypassing an Individual Menu Item EN-10
 - Entering the .S.E.T.U.P. Menu EN-11
 - Turning Display Hold or Totalize Mode On EN-11
 - Exiting the .S.E.T.U.P. Menu EN-12
 - Entering the .U.N.I.T. Menu EN-12
 - Parts Counting EN-13

TABLE OF CONTENTS (Cont.)

Calibration EN-13

 Span Calibration EN-13

 Linearity Calibration EN-14

Applications EN-15

 Weighing EN-15

 Weighing with Tare EN-15

 Parts Counting EN-16

 Percent Weighing EN-17

 Establishing a New Reference Weight EN-18

 Exiting Percent Weighing EN-18

 Display Hold EN-18

 Exiting Display Hold EN-19

 Totalize EN-19

 Clear Exit Totalize EN-20

Additional Features EN-20

 Weigh Below EN-20

 LFT (Legal for Trade on certain balances) EN-20

 Lock Switch EN-21

 Sealing the Balance EN-21

4. MAINTENANCE EN-22

 Cleaning EN-22

 Troubleshooting EN-22

 Error Codes List EN-23

 Accessories EN-24

5. TECHNICAL DATA EN-25

 Specifications EN-25

 Warranty EN-27

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*