



SERVICE MANUAL

SCOUT[®] *PRO* BALANCES

TABLE OF CONTENTS

	Page No.
CHAPTER 1 INTRODUCTION	
1.1 Introduction	1-1
1.2 Service Facilities	1-1
1.3 Tools and Test Equipment Required.....	1-2
1.3.1 Special Tools and Test Equipment List	1-2
1.3.2 Standard Tools and Test Equipment List	1-2
1.4 Test Masses Required	1-2
1.5 Specifications	1-3
CHAPTER 2 DIAGNOSIS	
2.1 Troubleshooting	2-1
2.2 Diagnostic Guide.....	2-1
2.2.1 Diagnosis.....	2-1
2.3 Error Codes	2-4
CHAPTER 3 REPAIR PROCEDURES	
3.1 Repair Procedures	3-1
3.1.1 Cover Removal	3-1
3.1.2 Printed Circuit Board Replacement	3-2
3.1.3 Transducer Replacement	3-4
CHAPTER 4 TESTING	
4.1 Testing	4-1
4.1.1 Operation Test	4-1
4.1.2 Segment Display Test.....	4-1
4.2 Performance Tests	4-1
4.2.1 Repeatability Test	4-2
4.2.2 Off-Center Load Test.....	4-3
4.2.3 Linearity Test	4-3
4.3 Down Stop Adjustment.....	4-4
CHAPTER 5 DRAWINGS AND PARTS LISTS	
5.1 Drawings	5-1
5.2 Parts Lists.....	5-3
APPENDIX A SERVICE TOOL INSTRUCTIONS	
A. Service Tools Instructions	A-1
A.1 Requirements for Scout Pro Tools	A-1
A.2 Software Installation	A-1
A.3 Hardware Installation	A-1
A.4 Special Instructions for USB Interface	A-2
A.5 Using Configtool.Exe	A-3
A.6 Final Service Calibration	A-5

APPENDIX B FACTORY CALIBRATIONS

	Page No.
B. Factory Calibrations	B-1
B.1 Service Calibration	B-1
B.2 Factory Calibration	B-3

LIST OF TABLES

TABLE NO.	TITLE	Page No.
1-1	Calibration Points	1-2
1-2	Specifications	1-3
2-1	Diagnostic Guide	2-2
2-2	Error Codes	2-4
4-1	Types of Performance Tests	4-1
4-2	Test Masses	4-3
4-3	Test Mass Values	4-5
4-4	Transducer Adjustment Tolerances	4-5
5-1	Replacement Parts List	5-3

LIST OF ILLUSTRATIONS

FIGURE	TITLE	Page No.
3-1	Shipping Lock	3-1
3-2	Bottom of Balance	3-1
3-3	Printed Circuit Board removal	3-2
3-4	Transducer Removal	3-4
4-1	LCD Full Display	4-1
4-2	Transducer Front View - Down Stop Adjustment	4-4
5-1	Scout Pro Exploded View	5-2
A-1	Screw and Housing Removal	A-2
A-2	Connector J3 Location	A-2
A-3	Connector J3 Shorted	A-2
A-4	Screen 1	A-3
A-5	Screen 2	A-4
A-6	Screen 3	A-4
A-7	Screen 4	A-5
B-1	IC U9 Connections	B-2

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*