

1400
PROFIBUS-DP
GATEWAY
Reference
Manual

For use with Software
Versions 1.xx

TABLE OF CONTENTS

1. INTRODUCTION	2
1.1. THE RANGER 1400 PROFIBUS GATEWAY	2
1.2. THE MANUALS.....	2
2. INSTALLATION	3
2.1. DIN-RAIL MOUNTING.....	3
2.2. ELECTRICAL CONNECTIONS	3
3. CONNECTORS AND INDICATORS	4
THE PROFIBUS RUN LED (GREEN)	4
3.2. THE PROFIBUS DEX LED (RED).....	4
3.3. SERIAL 1 AND SERIAL 2 LEADS.....	4
4. SYSTEM CONFIGURATION.....	5
4.1. WIRING OF THE RANGER NETWORK.....	5
4.2. CONFIGURATION OF THE RANGER DEVICES	6
4.3. CONFIGURATION OF RANGER 1400 PROFIBUS-DP GATEWAY.....	6
5. DATA FORMATS FOR DIGITAL INDICATORS	9
5.1. DIGITAL INDICATOR INPUT FORMAT	9
5.2. OUTPUT FORMAT COMMAND LEVEL 0.....	10
5.3. OUTPUT FORMAT COMMAND LEVEL 1	11
5.4. OUTPUT FORMAT COMMAND LEVEL 2.....	12
6. DATA FORMAT FOR REMOTE DISPLAYS.....	14
6.1. REMOTE DISPLAY INPUT FORMAT.....	14
6.2. REMOTE DISPLAY OUTPUT FORMAT	14
7. DIAGNOSTIC DATA	16
7.1. 1400 SPECIFIC DIAGNOSTICS	16
7.2. INDICATOR / DISPLAY SPECIFIC DIAGNOSTICS	17
8. SPECIFICATIONS	18

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*