

5000
Digital Indicator
Reference Manual

For use with Software Versions 4.6 and above

TABLE OF CONTENTS

1.	INTRODUCTION.....	4
1.1.	THE MANUALS	4
1.2.	THE 5000	4
2.	SPECIFICATIONS	5
3.	INSTALLATION	6
3.1.	INTRODUCTION.....	6
3.2.	PANEL MOUNTING	6
3.3.	DC POWER SUPPLY.....	6
3.4.	AC POWER SUPPLY.....	6
3.5.	LOAD CELL SIGNALS AND SCALE BUILD	6
3.6.	LOAD CELL CONNECTION.....	7
3.7.	INTRINSIC SAFETY	7
3.8.	SERIAL PORTS.....	8
3.9.	THE OPTION CARDS	9
4.	DISPLAY AND CONTROLS	10
4.1.	FRONT PANEL.....	10
4.2.	VISUAL DISPLAY	10
4.3.	CONTROL BUTTONS (5) AND (6).....	11
5.	BASIC OPERATION.....	12
5.1.	INTRODUCTION	12
5.2.	USING THE PRIMARY FUNCTIONS	12
5.3.	SETPOINTS - DIRECT OPERATOR ACCESS.....	13
6.	DIGITAL SETUP	14
6.1.	GENERAL SETUP INFORMATION.....	14
6.2.	OPERATION OF THE SETUP MENUS	18
6.3.	SCALE BUILD - (BUIlD).....	20
6.4.	SCALE OPTIONS - (OPTiON)	21
6.5.	SCALE CALIBRATION - (CAL).....	22
6.6.	COMMUNICATIONS OPTIONS - (SERIAL).....	23
6.7.	SPECIAL SETTINGS MENU - (SPEC)	25
6.8.	SPECIAL TEST SECTION - (TEST).....	26
6.9.	SET POINTS - (SET.PTS).....	26
6.10.	ANALOGUE SETTINGS - (ANALOG)	28
6.11.	CLOCK SETTINGS - (CLOC).....	28
6.12.	FACTORY ADJUSTMENT MENU - (FACTRY).....	29
6.13.	LEAVING DIGITAL SETUP	29
7.	CALIBRATION.....	30
7.1.	INTRODUCTION AND WARNINGS.....	30
7.2.	USING THE DIGITAL CALIBRATION WITH TEST WEIGHTS.....	30
7.3.	DIRECT MV/V CALIBRATION	31

7.4.	USING THE LINEARISATION	32
8.	THE SERIAL OUTPUTS	33
8.1.	INTRODUCTION	33
8.2.	SINGLE AND AUTOMATIC WEIGHT OUTPUT FROM THE 5000.....	33
8.3.	NETWORKING THE 5000	36
8.4.	PRINTER DRIVING.....	37
9.	SETPOINTS	41
9.1.	INTRODUCTION	41
9.2.	THE STATUS LEDS.....	41
9.3.	CONNECTION.....	41
9.4.	SETTINGS	41
9.5.	EXTENDED BATCHING OPERATION.....	44
10.	EXTENDED FUNCTIONS.....	50
10.1.	INTRODUCTION.....	50
11.	ACCESSORIES AND OPTIONS	52
11.1.	INTRODUCTION	52
11.2.	INSTALLING OPTION CARDS	52
11.3.	THE SETPOINT CARD	52
11.4.	THE ANALOGUE OUTPUT CARD	53
11.5.	THE 'COMBO' CARD	54
11.6.	FINE ADJUSTMENT OF ANALOGUE OUTPUTS	54
11.7.	LICENSING OPTIONS	55
12.	ERROR MESSAGES	56
12.1.	WEIGHING ERRORS	56
12.2.	SETUP ERRORS	56
12.3.	CALIBRATION ERRORS	56
12.4.	DIAGNOSTIC ERRORS	57
13.	SETUP MENU QUICK REFERENCE	58

SPECIAL NOTE
TRADE USE OF THE RANGER 5000

This manual may occasionally make reference to Trade Use settings of the **5000**. Only properly marked Trade Certified versions of the **5000** can be used in "Legal for Trade" applications.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/rinstrum/5000 reference manual.html](https://the-checkout-tech.com/manuals/rinstrum/5000%20reference%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)