

5100

Digital Indicator

Reference Manual

For use with Software Versions 3.1 and above

TABLE OF CONTENTS

1. INTRODUCTION 4
 1.1. THE MANUALS..... 4

2. SPECIFICATIONS..... 5

3. INSTALLATION..... 6
 3.1. PANEL MOUNTING 6
 3.2. DC POWER SUPPLY 6
 3.3. AC POWER SUPPLY 6
 3.4. LOAD CELL SIGNALS AND SCALE BUILD..... 6
 3.5. LOAD CELL CONNECTION 7
 3.6. SERIAL PORTS..... 7
 3.7. THE OPTION CARDS 8

4. DISPLAY AND CONTROLS..... 9
 4.1. FRONT PANEL 9
 4.2. VISUAL DISPLAY..... 9
 4.3. CONTROL BUTTONS (6) AND (7) 10
 4.4. DATA ENTRY MODES..... 11

5. BASIC OPERATION..... 13
 5.1. BASIC TERMINOLOGY 13
 5.2. USING THE PRIMARY KEY FUNCTIONS..... 13
 5.3. USING THE OPERATOR INTERFACE 15

6. APPLICATION CONFIGURATION ISSUES 17
 6.1. GENERAL SETUP INFORMATION 17

7. DIGITAL SETUP..... 21
 7.1. OPERATION OF THE DIGITAL SETUP MENUS..... 21
 7.2. SCALE BUILD - (BUILD) 22
 7.3. SCALE OPTIONS - (OPTION)..... 23
 7.4. SCALE CALIBRATION - (CAL) 25
 7.5. SPECIAL SETTINGS MENU - (SPEC)..... 25
 7.6. COMMUNICATIONS OPTIONS - (SERIAL)..... 27
 7.7. SET POINTS - (SET.PTS)..... 31
 7.8. ANALOGUE SETTINGS - (ANALOG)..... 33
 7.9. CLOCK SETTINGS - (CLOC) 34
 7.10. SPECIAL TEST SECTION - (TEST) 35
 7.11. FACTORY ADJUSTMENT MENU - (FACTRY)..... 35
 7.12. LEAVING DIGITAL SETUP - (-END-)..... 36

8. CALIBRATION 37
 8.1. PERFORMING A DIGITAL CALIBRATION WITH TEST WEIGHTS 37
 8.2. DIRECT mV/V CALIBRATION 38
 8.3. USING THE LINEARISATION 39

9. THE SERIAL OUTPUTS	41
9.1. SINGLE AND AUTOMATIC WEIGHT OUTPUT FROM THE 5100.....	41
9.2. NETWORKING THE 5100.....	44
9.3. PRINTER DRIVING	45
9.4. PLC OUTPUT DRIVING	49
10. SETPOINTS.....	50
10.1. CONNECTION.....	50
10.2. BASIC SETPOINT OPERATION	50
10.3. SETPOINT TYPES AND OPTIONS (SET.TYP)	53
10.4. GENERAL CONFIGURATION	56
10.5. OPERATOR PARAMETERS	59
10.6. FUNCTION KEY, EXTERNAL KEYS AND INTERLOCK	60
10.7. SETPOINT MESSAGES	62
10.8. SETPOINT PRINTING	62
10.9. PLC OUTPUT MODULE	63
11. EXTENDED FUNCTIONS.....	64
11.1. INTRODUCTION.....	64
11.2. EXTENDED FUNCTION DETAILS.....	64
12. ACCESSORIES AND OPTIONS	66
12.1. INTRODUCTION.....	66
12.2. INSTALLING OPTION CARDS	66
12.3. THE SETPOINT CARD.....	66
12.4. THE 'COMBO' CARD.....	67
12.5. SOFTWARE OPTIONS.....	69
13. ERROR MESSAGES	70
13.1. WEIGHING ERRORS.....	70
13.2. SETUP ERRORS.....	70
13.3. CALIBRATION ERRORS	70
13.4. DIAGNOSTIC ERRORS.....	71
14. SETUP MENU QUICK REFERENCE	72

**SPECIAL NOTE
TRADE USE OF THE RANGER 5100**

This manual may occasionally make reference to Trade Use settings of the **5100**. Only properly marked Trade Certified versions of the **5100** can be used in "Legal for Trade" applications.

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*