

**5230
(Truck Weigher)
Digital Indicator
Operator Manual**

For use with Software Versions 2.0 and above

5200-602-160

Table Of Contents

1.	INTRODUCTION	4
1.1.	Approvals.....	4
1.2.	Features	4
1.3.	Manuals	4
2.	SAFETY	4
2.1.	Operating Environment.....	4
2.2.	Cleaning	4
3.	BASIC OPERATION	5
3.1.	User Interface Display and Controls	5
3.2.	Keypad Buttons	5
3.3.	Auxiliary Display	8
3.4.	Status Annunciators	8
4.	BASIC WEIGHING	9
4.1.	Normal Weighing	9
4.1.1.	Print Currently Displayed Weight.....	9
4.2.	Managing IDs	9
4.2.1.	Display Total for Most Recent ID	9
4.2.2.	Search 10 Most Recent IDs.....	9
4.2.3.	Search All IDs.....	10
4.2.4.	Print All Truck/Product/Dest ID Totals	10
4.2.5.	Print and Clear All ID Totals	10
4.2.6.	Create New ID	11
4.2.7.	Delete ID.....	11
5.	TRUCK ID OPERATIONS	12
5.1.	Single Axle Weighing.....	12
5.1.1.	First Weigh (Single Axle)	13
5.1.2.	Second Weigh (Single Axle).....	14
5.1.3.	Preset Tare Truck Weigh (Single Axle)	15
5.2.	Multiple or Variable Axle Weighing	16
5.2.1.	First Weigh (Multiple / Variable Axles).....	17
5.2.2.	Second Weigh (Multiple / Variable Axles)	18
5.3.	Batching Process (Remote Fill)	19
6.	ERROR MESSAGES	20
7.	DIAGNOSTIC ERRORS	20

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/rinstrum/5230 operator manual.html](https://the-checkout-tech.com/manuals/rinstrum/5230%20operator%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)