




B220 / B225

Counting scales



Service Instructions

ENGLISH



Contents

page no.

1	Safety	5
1.1	Electrical installation	5
1.2	Risk of electric shock	5
1.3	Additional service precautions	6
1.4	Replacing batteries	6
1.5	Safe handling	6
1.6	ESD handling precautions	6
2	Displays and keys	7
2.1	Display	7
2.2	Keys	8
3	Configuration	11
3.1	Management mode	11
3.2	Restricted service access	12
3.3	Full service access	13
3.4	Verification mode	14
3.5	Navigating the menus	15
	Important: E30 error.	16
	Important: E200 message	16
	Important:Example: Updating your settings in management mode	16
3.6	Configuration summary	17
3.7	Configuration branches	18
4	PC protocol	47
5	Calibration	49
5.1	Normal calibration procedure	49
5.2	Calibrate Remote platform - B225 only	51
	5.2.1 Full load 5 step calibration	51
	5.2.2 Partial load 2 step calibration	52
5.3	Aborting calibration	54
6	Diagnostics	55
6.1	Status display	55
6.2	Error messages	56
7	Servicing	57
7.1	Removing the covers	57
7.2	Installing expansion boards	58

8	30 kg scales	59
8.1	Stiffener plate	59
9	Exploded diagram	60
10	Wiring / Connections	63
10.1	External connections	63
10.1.1	Serial output (Printer / PC connection)	63
10.1.2	External platform (B225 only)	64
10.2	Internal connections	65
Index		67

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*