

# C3235 Checkweigher

## User Instructions

### 1.0 Introduction

The C3235 is a checkweighing scale for the rapid indication of over, under or acceptable weight in a production environment. This manual covers the introduction to the unit, its use, configuration and calibration.

#### Front Panel

Figure 1.1 shows the front panel of the unit. The front panel includes the display window, the annunciators arrayed around the display, the four keys and the bubble level.




Figure 1.1 C3235 front panel

**NOTE:** This product is rated to IP54. Care must be taken to ensure that the power/mains plug does not become wet. If the product is required to be used while plugged into the outlet/mains, the plug must either be located outside the wet area, or must be plugged into a socket which provides suitable IP rating with the plug mated.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/Salter Brecknell/C-3235 instructions and calibration>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)