


# *Weight indicator PR 1612/02*

*Operating manual*



## **CONTENTS**

PART 1	PREFACE, DESCRIPTION
PART 2	SAFETY INSTRUCTIONS
PART 3	TECHNICAL DATA
PART 4	MOUNTING, INSTALLATION AND LOADCELL CONNECTION
PART 5	OPERATION
PART 6	SETTING AND CALIBRATION
PART 7	HW-OPTIONS, APPLICATION, and INTERFACING
PART 8	COMMUNICATING WITH SUPERORDINATE OR SUBORDINATE INSTRUMENTS / SYSTEMS
PART 9	SHORT FORM DESCRIPTION FOR SETTING AND CALIBRATION
PART 10	INDEX
APPENDIX 1	CORNER POINT ADJUSTMENT
APPENDIX 2	INCREMENTAL CALIBRATION WITH MAKE-UP WEIGHT

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*