

Operating manual PR 1713/00



Operating manual 9499-050-42910 Release 1.x

Other Manuals for PR1713:

Installation manual	9499-053-43010	Release 1.0
System manual	9499-054-43110	Release 1.x

(general)

Batching manual	9499-057-43210	Release 1.x
Programming	9499-053-35410	Release 1.x

CONTENTS

1 INTRODUCTION	4
1.1 GENERAL	4
<i>1.1.1 Manual repartition.....</i>	<i>4</i>
<i>1.1.2 Instrument description.....</i>	<i>4</i>
2 DESCRIPTION OF CONTROLS	6
2.1 DISPLAY	6
2.2 KEYBOARD.....	7
2.3 OPERATING CONCEPT	8
<i>2.3.1 Operation via 'soft'-key.....</i>	<i>9</i>
<i>2.3.2 Selecting from selection boxes.....</i>	<i>10</i>
<i>2.3.3 Editing with alphanumeric characters</i>	<i>11</i>
3 MAIN MENU	13
3.1 BOOT MENU	13
4 FIXTARE	15
5 COUNTING SCALE.....	17
6 BATCHING.....	19
6.1 INPUT MENU FOR COMPONENT EDITING	20
<i>6.1.1 Editing.....</i>	<i>20</i>
<i>6.1.2 Component parameters.....</i>	<i>23</i>
<i>6.1.2.1 Batch Mode.....</i>	<i>23</i>
<i>6.1.2.2 SPM output address</i>	<i>27</i>
<i>6.1.2.3 SPM input address</i>	<i>27</i>
<i>6.1.2.4 Preset Point</i>	<i>27</i>
<i>6.1.2.5 Overshoot.....</i>	<i>27</i>
<i>6.1.2.6 + Tolerance, - Tolerance.....</i>	<i>27</i>
<i>6.1.2.7 Minimum Flowrate</i>	<i>28</i>
<i>6.1.2.8 Calming time.....</i>	<i>28</i>
<i>6.1.2.9 Restart mode</i>	<i>29</i>
<i>6.1.3 Deleting.....</i>	<i>31</i>
<i>6.1.4 Printing</i>	<i>31</i>
6.2 INPUT MENU FOR RECIPE EDITING	32
<i>6.2.1 Editing.....</i>	<i>32</i>
<i>6.2.2 Recipe total mode.....</i>	<i>35</i>
<i>6.2.3 Setpoint scaling.....</i>	<i>36</i>
<i>6.2.4 Simulation</i>	<i>36</i>
<i>6.2.5 Deleting.....</i>	<i>37</i>
<i>6.2.6 Printing</i>	<i>37</i>

6.3 STARTING A BATCH PROCESS.....	38
6.3.1 <i>Status display</i>	38
6.3.2 <i>Stopping the batch process</i>	38
6.3.3 <i>Continue, skip, abort.....</i>	39
6.3.4 <i>Messages during batching</i>	39
6.4 SELECTING A REPORT	40
6.4.1 <i>Consumption</i>	40
6.4.2 <i>Production report.....</i>	41
6.4.3 <i>Last batch report.....</i>	42
6.5 ADDRESS LAYOUT OF SIGNALS	43
6.5.1 <i>Digital in- and outputmodules PR1713/12.</i>	43
6.5.2 <i>SPM-addresses for addressing the digital outputs</i>	45
7 ANALOG TEST.....	47
8 SETUP.....	49
9 WHAT CAN BE DONE IN CASE OF TROUBLE.....	51
9.1 ERROR MESSAGES.....	51
9.1.1 <i>Error messages on the weight display</i>	51
9.2 ERROR MESSAGES ON THE TEXT DISPLAY	52
10 INDEX.....	53

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sartorius/PR-1713 operating manual.html](https://the-checkout-tech.com/manuals/sartorius/PR-1713%20operating%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)