

Table of Contents

- Introduction 3
- Supervisor Setup 9
 - Soft Key: PRINT SETUP 10
 - Soft Key: SAMPLE SETUP 18
 - Soft Key: ACCURCY SETUP 20
 - Soft Key: PORTS SETUP 22
 - Soft Key: TIME/DATE 24
 - Soft Key: UNITS ENABLED 28
 - Soft Key: DATABASE SETUP 32
 - Soft Key: TRANSAC SETUP 36
 - Soft Key: ID NAME SETUP 40
 - Soft Key: MACRO SETUP 44
 - Soft Key: SETUP SECURTY 54
 - Soft Key: BEEPER CONTROL 56
- Bases Setup 59
 - Soft Key: CALIB 60
 - Soft Key: SPEED 64
 - Soft Key: ZERO 66
 - Soft Key: RESOLUT 68
 - Soft Key: INFO 70
 - Soft Key: NAME 72
 - Soft Key: ADDRESS 74
 - Soft Key: BASERST 78
- Technical Setup 81
 - Soft Key: GREETNG 82
 - Soft Key: BACKLIT 84
 - Soft Key: SETUP TRANSFR 88
 - Soft Key: RESET 92

Soft Key: AUTO SWITCH	96
Soft Key: ALARMS	98
Soft Key: DIG INP	102
Soft Key: SETUP SECURTY	104
Soft Key: HYSTERS	106
Soft Key: APW QTY	108
Appendix A: RS232 Serial Port Communications	111
Appendix B: Scriptcoder™ Custom Label Printing	119
Appendix C: Setra Dialog Language	127
Appendix D: Battery Option	130
Appendix E: Strain Gauge Remote Scale Option	132
Appendix F: Relay Box	138
Appendix G: Glossary	142
Appendix H: Specifications	144
Appendix I: Warranty	147
Appendix J: Warnings	148
FCC Warning	149
EC Declaration of Conformity	150
Index	151

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*