

DJ series

OPERATION MANUAL



SHINKO

Tokyo

CONTENTS

INTRODUCTION TO DJ SERIES.....	2
GENERAL SPECIFICATIONS.....	2
EXTERNAL VIEW & NAMES OF PARTS.....	3
MODELS.....	3
DISPLAY PANEL.....	4
KEY FUNCTIONS.....	4
INSTALLATION.....	5
1. Location.....	5
2. Unpacking.....	5
3. Loading Weighing Pan.....	5
4. Leveling.....	5
PERFORMANCE TEST.....	6
OPERATION.....	7
1. Taring & Weighing.....	7
2. To read Additional Weight.....	7
CONVENIENCES FOR USERS.....	8
1. Power Indicator.....	8
2. Bar Graph.....	8
3. Unstable Sign.....	8
4. Zero/Tare Indicator.....	8
5. Overload.....	8
VARIOUS FUNCTIONS.....	9
1. Items/Parameters/Contents.....	9
2. How to Verify Settings/Change Parameters.....	10
SPAN CALIBRATION.....	11
1. Span Calibration for DJ-E Models.....	11
2. Span Calibration for DJH-E Models.....	13
TROUBLESHOOTINGS.....	15
OPTIONS.....	16
1. Printer.....	16
2. Battery.....	17

° ° °

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*