

AHC - QHC SERIES

Counting Scale Technical Manual

TSCALE

Contents

1. Precautions.....	3
2. Installation.....	4
3. Name and functions.....	6
Key board.....	6
Display.....	8
4. Operation.....	9
Power ON/OFF	9
Zero.....	9
Tare.....	9
5. Parts Counting	10
Setting unit weight.....	10
Entering a known unit weight.....	10
Parts counting.....	10
Automatic part weight updates.....	10
Setting high / low limits	11
Checking Alarm.....	11
Accumulation.....	11
Automatic Accumulated Totals.....	11
Auto Off	11
Display back light.....	11
6. Parameter.....	12
Parameter block.....	12
Setting parameters	12
7. RS232 Protocol.....	18
Specification.....	18
Connector.....	18
Commands.....	18
Communication.....	18
8. Error codes.....	21
9. Drawing.....	22
Parts list.....	23
10. Dimension.....	24
11. Specifications.....	24
Load cell specifications.....	25

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/T-Scale/AHC series and QHC series service and](https://the-checkout-tech.com/manuals/T-Scale/AHC%20series%20and%20QHC%20series%20service%20and%20repair%20manual.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://the-checkout-tech.com)