

TSCALE

NB/NHB series

Electronics balances

Service manual

Contents

SECTION 1 INTRODUCTION.....	1
SECTION 2 SPECIFICATIONS.....	2
SECTION 3 INSTALLATION.....	3
SECTION 4 KEY DESCRIPTIONS.....	4
SECTION 5 OPERATION.....	5
5.1 Zeroing the display.....	5
5.2 Taring.....	5
5.3 Weighing a sample.....	5
5.4 Percent weighing.....	5
5.5 Parts counting.....	6
5.6 Accumulated.....	6
SECTION 6 BATTERY OPERATION.....	7
SECTION 7 INTERFACE.....	8
7.1 RS-232.....	8
7.2 USB interface.....	8
SECTION 8 PARAMETERS.....	10
SECTION 9 APPENDIX.....	12
9.1 Error code.....	12
9.2 Weighing unit listing.....	12
SECTION 10 TROUBLE SELF CHECKING.....	13
SECTION 11 TROUBLE SHOOTING.....	14
11. 1 no power.....	14
11. 2 no display.....	15
11. 3 can't charge the battery.....	16
11. 4 can't weigh.....	17
11. 5 unstable.....	18

11. 6 can't use keyboard.....	18
SECTION 12 CAHNGE PARTS PROCESS.....	19
12. 1 replace main board.....	19
12. 2 replace display board.....	19
12. 3 replace load cell.....	19
12. 4 replace MPU.....	20
12. 5 replace battery.....	20
SECTION 13 APENDIX.....	21
13. 1-1 schematic (main).....	21
13.1- 2 schematic (ADC).....	22
13.1- 3 schematic (display).....	23
13 1-4 schematic (power).....	24
13.1- 5 schematic interface.....	25
13.1-6 Schematic (Other)	26
13.2-1parts drawing(150g~3000g).....	27
13.2-2 parts drawing(6000g).....	29
13.3 numeric and alphabetic characters display on LCD.....	31

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*