

***TEC***

TEC Electronics Computing Scale

# **SL21-N SERIES**

## **Initial Setting Manual**

Document No. **EM3-31006**

Original **Apr., 1990**

(Revised            )

**TOKYO ELECTRIC CO., LTD.**

## CONTENTS

	Page
1. OUTLINE OF INITIAL SETTING .....	1
2. SWITCH AND KEY FUNCTIONS IN INITIAL SETTING .....	2
2.1. Initial Switch .....	2
2.2. Operation Switch and Keys .....	2
3. FUNCTION TABLE FOR P2 MODE .....	3
4. INITIAL SETTING .....	20
4.1. How to Place the Scale in Initial Set Mode .....	20
4.2. Initial Set Mode [P0] .....	20
4.3. Initial Set Mode [P1] .....	23
4.4. Initial Set Mode [P2] .....	27
4.5. Initial Set Mode [P3] .....	29
5. STOPPER ADJUSTMENT .....	30
5.1. Adjustment of Platter Frame Stoppers .....	30
5.2. Adjustment of Load Cell Stopper .....	31
6. STANDARD SETTINGS BY COUNTRY OF DESTINATION ..	32

Quality: Good

NOTE: Section 4.3 is complete, page 25 and 26 are presumed blank.

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*