


TEC Digital Scale

SL-47-N-1 SERIES

Owner's Manual

Document No. EM1-31061A



TEC CORPORATION

TABLE OF CONTENTS

		Page
1.	INTRODUCTION	1- 1
2.	APPLICABLE MODEL	2- 1
3.	SPECIFICATIONS	3- 1
4.	OVERVIEW	4- 1
5.	LEVEL ADJUSTMENT	5- 1
6.	INSTALLING THE REMOTE PIPE	5- 1
7.	CONNECTING THE INTERFACE CABLE AND REMOTE CABLES	7- 1
8.	TROUBLESHOOTING	8- 1
q	BEFORE YOU CALL FOR SERVICE	8. 1

CAUTION:

- 1. This manual may not be copied in whole or in part without prior written permission of TEC.
- 2. The contents of this manual may be changed without notification.
- 3. Please refer to your local Authorized Service representative with regard to any queries you may have in this manual.

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/TEC/SL-47-Series owners manual.html

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM