




TEC Digital Scale

SL-47-N-1 SERIES

Owner's Manual

Document No. EM1-31061A



TEC CORPORATION

TABLE OF CONTENTS

	Page
1. INTRODUCTION	1- 1
2. APPLICABLE MODEL	2- 1
3. SPECIFICATIONS	3- 1
4. OVERVIEW	4- 1
5. LEVEL ADJUSTMENT	5- 1
6. INSTALLING THE REMOTE PIPE	5- 1
7. CONNECTING THE INTERFACE CABLE AND REMOTE CABLES	7- 1
8. TROUBLESHOOTING	8- 1
9. BEFORE YOU CALL FOR SERVICE	8- 1

CAUTION:

1. *This manual may not be copied in whole or in part without prior written permission of TEC.*
2. *The contents of this manual may be changed without notification.*
3. *Please refer to your local Authorized Service representative with regard to any queries you may have in this manual.*

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)