




TEC Electronic Computing Scale  
**SL-5900 (US. Version)**

**Owner's Manual**

Document No. EM1-31015



## TABLE OF CONTENTS

	Page
● INTRODUCTION .....	1
1. SPECIFICATIONS .....	5
2. OVERVIEW .....	7
3. REMOTE DISPLAY .....	7
4. KEY LAYOUT .....	8
5. KEY FUNCTIONS .....	10
6. LAMP FUNCTIONS .....	13
7. CONTROL LOCK .....	14
8. LEVEL ADJUSTMENT .....	15
9. CLEANING THE PRINT HEAD .....	15
10. REMOVAL AND REPLACEMENT OF LABEL ROLL .....	16
11. REPORT PAPER THREADING .....	17
12. BEFORE STARTING OPERATION .....	17
13. OPERATING PROCEDURES .....	18
13.1 Weighed Commodity Registration .....	18
13.2 Fix Price Registration .....	21
13.3 By Count Registration (standard function) .....	22
13.4 By Count Registration (optional function by initial setting) .....	24
13.5 Tare Function Procedures .....	27
13.6 SAVE Key Operation Sample .....	28
13.7 VOID Key Operation Sample .....	29
13.8 Date Change .....	29
13.9 Calling And Printing A Grade Line .....	30
13.10 Entry By Clerk .....	31
13.11 Add Entry By Clerk .....	32
13.12 Multiple Weight .....	33

	Page
14. TOTAL OPERATION PROCEDURES .....	34
14.1 Hourly Total Report .....	34
14.2 Grand Total Report .....	35
14.3 PLU Total Report .....	36
14.4 Clerk Total Report .....	40
15. LIST UP OF PLU DATA .....	42
16. PROGRAMMING PROCEDURES .....	45
• Selection of Programming Menu .....	45
Menu No. 0 : Changing Unit Price or Price .....	46
Menu No. 1 : Setting or Changing PLU Data .....	47
Menu No. 2 : Setting Store Address or Commercial Message .....	52
Menu No. 3 : Adjusting Print Position for Label .....	53
Menu No. 4 : Setting Date, Time, Machine Number, and Store Number .....	54
Menu No. 5 : CMT Operations .....	55
Menu No. 7 : Changing Bar Code Format .....	57
Menu No. 8 : Assigning Speed Keys .....	60
Menu No. 11 : Setting Ingredient (for SL-5900-36 only) .....	61
Menu No. 12 : Issuing Confirmation Label (for SL-5900-35/36 only) .....	63
Menu No. 13 : Switching On-Line/Local (for SL-5900-35/36 only) .....	64
Menu No. 17 : Setting Grade Line (for SL-5900-36 only) .....	65
Menu No. 18 : Memory Card (for SL-5900-36 only) .....	66
Menu No. 20 : Transmitting PLU File or Unit Price (FUN System) .....	69
Menu No. 21 : Setting Clerk Name (for SL-5900-36 only) .....	70
Menu No. 40 : Setting Print Item #1 ON/OFF .....	72
Menu No. 41 : Setting Print Item #2 ON/OFF .....	73
17. ERROR MESSAGE TABLE .....	74
18. BEFORE YOU CALL FOR SERVICE .....	75

**CAUTION:**

1. *This manual may not be copied in whole or in part without prior written permission.*
2. *The contents of this manual may be changed without prior notice.*
3. *Please refer to your local Authorized Service representative with regard to any queries you may have in this manual.*

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*