



TRANSCELL TECHNOLOGY, INC.

NEPTUNE-5500

Series

CHECK WEIGHING SCALE

Operation Manual

Revision 2.7
June 29.2004

© 2003 Transcell Technology, Inc.

Contents subject to change without notice.

Transcell Technology, Inc.
975 Deerfield Parkway
Buffalo Grove, IL 60089
Tel (847) 419-9180
Fax (847) 419-1515
E-mail: transcell@transcell.net
Web: www.transcell.net

TABLE OF CONTENTS

	<u>Page</u>
Chapter 1: Introduction to the Transcell NEPTUNE-5500 Series Check Weighing Scale	5
Chapter 2: Getting Started.....	6
2.1 Installation.....	6
2.1.1 Stainless steel enclosure (NEPTUNE 5500)	6
2.2 Connecting the weigh platform to the indicator	7
2.3 Connecting the Serial printer, remote display or computer	8
2.4 Connecting to the Power Supply	8
Chapter 3: Basics of Operation	9
3.1 Keyboard.....	9,10
3.1.1 Light Emitting Diode (LED)	9
3.2 Display	11
3.3 General Scale Operation	12
3.3.1 Weighing an Item.....	12
3.3.2 Taring an Item of Unknown Weight	12
3.3.3 Taring an Item of Known Weight	12
3.3.4 Clearing a Tare	12
3.3.5 Entering a min and max value	12
Chapter 4: Advanced Features and Operation.....	13
4.1 Item ID Storage.....	13
4.1.1 Adding a New ID	13
4.1.2 Recalling an ID Entry	13
4.1.3 Deleting an Item Entry	13
4.1.4 Editing an Item Entry	14
4.2 TTL Outputs.....	14
4.2.1 Set point outputs.....	14
4.2.2 Disable set point mode	14
Chapter 5: Calibration.....	15
5.1 Calibration Overview.....	15
5.2 Zero Calibration	15
5.3 Span Calibration	16
5.4 View Calibration	17
5.5 Key-in calibration	17
Chapter 6 Configuration Overview	18
6.1 Configuration overview	18
6.2.1 Entering the setup menu.....	18
6.2.2 Navigating the setup menu.....	18
“F” Configuration menu.....	19
“A” Setup menu.....	22

LIST OF FIGURES

1-1	NEPTUNE-5500 Series Front Panel	5
2-1	NEPTUNE-5500 Main Circuit Board	7
2-2	Load cell connections.....	7
2-3	Pin assignments for load cell	7
3-1	NEPTUNE-5500 Keyboard Detail	9
3-2	Display detail	10,11

LIST OF TABLES

1-1	NEPTUNE-5500 Series Product Matrix.....	5
2-1	Keypad function	10
3-1	NEPTUNE-5500 Series Announcer Definitions.....	10, 11
6-1	Configuration Sub-Menu Items.....	20, 23

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/transcell/Neptune-5500 Series operation manual](https://the-checkout-tech.com/manuals/transcell/Neptune-5500%20Series%20operation%20manual.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)