COMPLETE MANUAL

WEIGHING INDICATOR TI-1200 and TI-1200-S

<u>TI-1200 with rechargeable battery.</u>

<u>TI-1200-S</u> without rechargeable battery and with a smaller cabinet.

Note: When TI-1200 is shipped as a part of a complete Scale e.g. AV-250-seies and AL-100-21, the Scales are normally calibrated. When TI-1200 is shipped together with Loadcells it is adjusted to the application but a calibration is always needed at the place of installation.

EC type-approved non-automatic weighing instrument Number FI 01.1.04
Accuracy class Ⓘ ⓘ ⓘ

INTRODUCTION TO THE TI-1200 DIGITAL INDICATOR

TI-1200 Digital Indicator is a general purpose, industrial grade weight indicator.

TI-1200 comes with an internal 6V rechargeable battery, are capable of driving four 350 ohm load cells and operate identically. All readout up to 50,000 display divisions on a liquid crystal display (LCD) with back light. All set up parameters may be entered via the front panel keys, including calibration.

An external power supply is included. The external power supply functions (9 VDC) as a charger* for the rechargeable battery. The power supply may also be used as the main power supply.

TEST CERTIFICATE: Number FIT 01.I.02 class Ⓘ

TI-1200 has 2 menues for configuration:
- Setup ("F") which configure the Indicator to your weighing application.
- User ("A") which configure the Indicator to the serial communication.

*Models:
TI-1200   : With rechargeable battery. Supply 9 VDC.
TI-1200-S   : Without rechargeable battery. Supply 9 VDC. Smaller cabinet

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/transcell/TI-1200 TI-1200-S complete manual.htm

And our free Online Keysheet maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM