

# **MAINTENANCE MANUAL**

## **GM,EBW,HBW,HFW SERIES**

**MODELS: GM-3000 GM-6000 GM-15K GM-30K  
GM-1100 GM-11K**

**EBW-60K EBW-120K**

**HBW-30K HBW-60K HBW-150K**

**HFW-60K HFW-150K HFW-300K**

### **CONTENTS:**

---

<b>1 INTRODUCTION</b>	<b>1</b>
<b>2 BLOCK DIAGRAM</b>	<b>13</b>
<b>3 POWER SUPPLY SECTION</b>	<b>14</b>
<b>4 TROUBLE SHOOTING</b>	<b>16</b>
<b>5 FLOW CHART I ( Calibration for end-user )</b>	<b>19</b>
<b>6 FLOW CHART II ( Calibration for technicians )</b>	<b>20</b>
<b>F1. Dealer Calibration</b>	
<b>F2. Display / Segment Check</b>	
<b>F3. Offset Value</b>	
<b>F4. Automatic Shut-off function</b>	
<b>7 PARTS LIST</b>	<b>26</b>
<b>8 SCHEMATICS</b>	<b>41</b>
<b>9 COMPONENTS LAYOUT</b>	<b>49</b>
<b>10 PCB LAYOUT</b>	<b>54</b>
<b>APPENDIX A</b>	
<b>APPENDIX B</b>	
<b>APPENDIX C</b>	
<b>APPENDIX D</b>	

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/UWE/GM EBW HBW HFW service manual.html](https://the-checkout-tech.com/manuals/UWE/GM%20EBW%20HBW%20HFW%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)