

MAINTENANCE MANUAL

GS SERIES

MODELS: GS-1200 GS-1500 GS-3000
GS-6000 GS-12K GS-15K

CONTENTS

1	INTRODUCTION	1
2	SPECIFICATION	2
	1. SYSTEM BLOCK DIAGRAM	
	2. PHYSICAL LAYOUT OF ELECTRICAL CONNECTION	
	3. GENERAL SPECIFICATION	
3	INITIAL SETUP	7
	1. INTERNAL FUNCTIONS AND ALTERNATE DIVISION	
	2. AUTO AND DEALER CALIBRATION	
	3. DISABLE CALIBRATION WITH DIP SW.(S1)	
	4. OFFSET AND SPAN VALUE DATA	
	5. FLOW CHART	
4	TROUBLE SHOOTING	14
	1. TROUBLE SHOOTING LOOP	
	2. PARTS AND COMPONENTS TROUBLE SHOOTING	
5	ELECTRICAL CIRCUITRY	19
	1. SCHEMATICS	
	2. PCB LAYOUT	
6	PARTS LIST	25
7	APPENDIX	29

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*