

MAINTENANCE MANUAL

HGS SERIES

**MODELS: HGS-300 HGS-600 HGS-1500
HGS-3000 HGS-6000 HGS-7500
HGS-15K**

CONTENTS

PAGE NO.

1 INTRODUCTION.....	1
2 SPECIFICATION.....	2
1. SYSTEM BLOCK DIAGRAM	
2. PHYSICAL LAYOUT OF ELECTRICAL CONNECTION	
3. GENERAL SPECIFICATION	
3 INITIAL SETUP.....	6
1. INTERNAL FUNCTIONS AND ALTERNATE DIVISION	
2. AUTO AND DEALER CALIBRATION	
3. DISABLE CALIBRATION WITH DIP SW.(S1)	
4. OFFSET AND SPAN VALUE DATA	
5. FLOW CHART	
4 TROUBLE SHOOTING.....	15
1. TROUBLE SHOOTING LOOP	
2. PARTS AND COMPONENTS TROUBLE SHOOTING	
5 ELECTRICAL CIRCUITRY.....	19
1. SCHEMATICS	
2. PCB LAYOUT	
6 PARTS LIST.....	25
7 APPENDIX.....	29

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/UWE/HGS service manual.html](https://the-checkout-tech.com/manuals/UWE/HGS%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)