MAINTENANCE MANUAL HGS SERIES

MODELS: HGS-300 HGS-600 HGS-1500 HGS-3000 HGS-6000 HGS-7500 HGS-15K

CONTENTS PAGE NO. 1 INTRODUCTION...... 2 SPECIFICATION.....2 1. SYSTEM BLOCK DIAGRAM 2. PHYSICAL LAYOUT OF ELECTRICAL CONNECTION 3. GENERAL SPECIFICATION 3 INITIAL SETUP......6 1. INTERNAL FUNCTIONS AND ALTERNATE DIVISION 2. AUTO AND DEALER CALIBRATION 3. DISABLE CALIBRATION WITH DIP SW.(S1) 4. OFFSET AND SPAN VALUE DATA 5. FLOW CHART 4 TROUBLE SHOOTING......15 1. TROUBLE SHOOTING LOOP 2. PARTS AND COMPONENTS TROUBLE SHOOTING 5 ELECTRICAL CIRCUITRY......19 1. SCHEMATICS 2. PCB LAYOUT 6 PARTS LIST......25 7 APPENDIX......29

This is a "Table of Contents preview" for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<u>http://the-checkout-tech.com</u>: the biggest supplier of cash register and scale manuals on the net