UWE LM operation Manual

LM SERIES

BENCH/FLOOR SCALE

OPERATION MANUAL

PLEASE READ THIS INSTRUCTION MANUAL VERY CAREFULLY BEFORE ATTEMPTING TO OPERATE THIS SCALE

AUGUST 2003 REV 1

Specifications subject to change without prior notice

CONTENTS

- 1 INSTALLATION
- 2 SPECIFICATIONS
- 3 KEYBOARD LAYOUT AND DESCRIPTION
- 4 INSTRUCTIONS FOR USE
- 5 TROUBLE SHOOTING
- 6 DAILY CARE AND MAINTENANCE
- 7 INSTALLATION DIAGRAMS

This is a "Table of Contents preview" for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<u>http://the-checkout-tech.com</u>: the biggest supplier of cash register and scale manuals on the net