

## **MAINTENANCE MANUAL**

### **OAP PRICE COMPUTING SERIES**

**MODELS: OAP-6, OAP-15 & OAP-30**

#### **CONTENTS**

- 1. INTRODUCTION**
- 2. SPECIFICATIONS**
  - 2.1 SYSTEM BLOCK DIAGRAM
  - 2.2 PHYSICAL LAYOUT OF ELECTRICAL CONNECTION
  - 2.3 GENERAL SPECIFICATIONS
- 3. INITIAL SETUP**
  - 3.1 INTERNAL FUNCTION AND SETUP PROCEDURES
  - 3.2 COUNTRY CODE AND EURO EXCHANGE RATE
  - 3.3 AUTO AND DEALER CALIBRATION PROCEDURES
  - 3.4 OFFSET AND SPAN VALUE DATA
  - 3.5 FLOW CHART
- 4. TROUBLE SHOOTING**
  - 4.1 TROUBLE SHOOTING LOOP
  - 4.2 PARTS AND COMPONENTS TROUBLE SHOOTING
- 5. ELECTRICAL CIRCUITRY**
  - 5.1 SCHEMATICS
  - 5.2 PCB LAYOUTS
- 6. BILL OF MATERIAL**
- 7. APPENDIX**

NOVEMBER 1999 REV 3

*Specifications and Function Subject to Change without Notice*

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/UWE/OAP-6 OAP-15 OAP-30 service manual.htm>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)