## MAINTENANCE MANUAL

## **PSC SERIES**

MODELS: PSC-2.4 PSC-6 PSC-12 PSC-24 PSC-60 PSC-120 PSC-240

CONTENTS

1 INTRODUCTION 1 2 SPECIFICATION 2 **1. SYSTEM BLOCK DIAGRAM** 2. PHYSICAL LAYOUT OF ELECTRICAL CONNECTION **3. GENERAL SPECIFICATION 3 INITIAL SETUP 8 1. INTERNAL FUNCTIONS AND SETTING METHODS** 2. AUTO AND DEALER CALIBRATION PROCEDURES 3. DISABLE CALIBRATION WITH DIP SW.(S1) 4. OFFSET AND SPAN VALUE DATA 5. FLOW CHART 4 TROUBLE SHOOTING 16 **1. TROUBLE SHOOTING LOOP** 2. PARTS AND COMPONENTS TROUBLE SHOOTING 5 ELECTRICAL CIRCUITRY 21 **1. SCHEMATICS** 2. PCB LAYOUT 6 PARTS LIST 31 7 APPENDIX 39

Specifications and functions subject to change without prior notice

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store: https://the-checkout-tech.com/manuals/UWE/PSC service manual.html

And our free Online Keysheet maker: https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM