

MAINTENANCE MANUAL

UFM SERIES

NTEP & MEASUREMENT CANADA

CONTENTS

- 1. INTRODUCTION**
- 2. SPECIFICATIONS**
 - 2.1 SYSTEM BLOCK DIAGRAM
 - 2.2 PHYSICAL LAYOUT OF ELECTRICAL CONNECTION
 - 2.3 GENERAL SPECIFICATIONS
 - 2.4 INTERNAL SETTINGS AND CALIBRATION METHODS
- 3. TROUBLE SHOOTING**
 - 3.1 TROUBLE SHOOTING LOOP
 - 3.2 PARTS AND COMPONENTS TROUBLE SHOOTING
- 4. ELECTRICAL CIRCUITRY**
 - 4.1 SCHEMATICS
 - 4.2 PCB LAYOUT
- 5. BILL OF MATERIAL**
- 6. APPENDIX**

JANUARY 2005 REV 2

Specifications and Function Subject to Change without Notice

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/UWE/UFM service manual.html](https://the-checkout-tech.com/manuals/UWE/UFM%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)