

MAINTENANCE MANUAL

W10 INDICATOR SERIES

CONTENTS

1. INTRODUCTION
2. SPECIFICATIONS
 - 2.1 SYSTEM BLOCK DIAGRAM
 - 2.2 PHYSICAL LAYOUT OF ELECTRICAL CONNECTION
 - 2.3 GENERAL SPECIFICATIONS
 - 2.4 OPTIONAL INTERFACE
 - 2.5 LOAD CELL CONNECTION
3. INITIAL SETUP
 - 3.1 INTERNAL FUNCTIONS AND SETTING METHODS
4. TROUBLE SHOOTING
 - 4.1 TROUBLE SHOOTING LOOP
 - 4.2 PARTS AND COMPONENTS TROUBLE SHOOTING
5. ELECTRICAL CIRCUITRY
 - 5.1 SCHEMATICS
 - 5.2 PCB LAYOUT
6. BILL OF MATERIAL
7. APPENDIX

NOV 2001 REV

1

Specifications and Function Subject to Change without Notice

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/UWE/W10 service manual.html](https://the-checkout-tech.com/manuals/UWE/W10%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)