

UNIVERSAL WEIGHT ENTERPRISE



W-22

Operation Manual

VER: 2.0.1

July/2004

1.	<i>HARD WARE SPECIFICATION :</i>	4
1.1.	SPECIFICATION	4
1.2.	STRUCTURE	5
1.3.	BACK VIEW.....	8
1.4.	LOAD CELL CONNECTION PICTURE	9
1.5.	RS-232 INTERFACE (D-SUB 9PIN).....	10
1.6.	RELAY OUTPUT	11
2.	QUICK OPERATION INTRODUCTION:	12
3.	PARAMETER SETTING:	13
3.1.	DIGITAL FILTER SETUP: (DEFAULT = 5)	13
3.2.	RS-232 BAUD RATE SETUP: (DEFAULT = 9600 BPS).....	14
3.3.	RS-232 DATA PROTOCOL SETUP: (DEFAULT = E.7.1).....	14
3.4.	DATA TRANSMISSION MODE:.....	14
3.5.	DATA FORMAT: (DEFAULT = FORT3)	15
3.6.	OPERATION MODE SETUP: (DEFAULT : M_HILO).....	17
3.7.	RELAY OUTPUT SETUP: (DEFAULT = OUT_HI).....	18
3.8.	BACKLIGHT SELECTION: (DEFAULT = 3 SEC)	18
3.9.	RELAY OUTPUT ZERO RANGE SETUP: (DEFAULT = 0)	18
3.10.	AUTO POWER OFF SETUP: (DEFAULT = 30 MIN).....	18
3.11.	AUTO ZERO TRACKING RANGE SETUP: (DEFAULT = 0)	19
3.12.	DATE SETUP:	19
3.13.	TIME SETUP:	19
3.14.	BEEP MODE SETUP: (DEFAULT = BEPOFF)	20
3.15.	PASSWORD SETUP: (DEFAULT = 0).....	20
4.	CALIBRATION:	21
4.1.	CALIBRATION AND PARAMETER SETUP	21
4.2.	CALIBRATION	22
4.3.	WEIGHT CORRECTION (LINEARITY CORRECTION)	23
4.4.	DECIMAL POINT SETUP:.....	23
4.5.	POWER ON WEIGHT UNIT SETUP:	24
4.6.	ZERO TRACKING RANGE SETUP: (DEFAULT = 1.5DIV / 1SEC).....	24
4.7.	POWER ON AUTO ZERO RANGE SETUP: (DEFAULT = 0%)	24
4.8.	MANUAL ZERO RANGE SETUP: (DEFAULT = 100%)	25
4.9.	INSTABILITY DETECTION SETUP: (DEFAULT = 1.0-0.5).....	25
5.	APPLICATION EXAMPLE:	26

5.1.	WEIGHT CHECKING:	26
6.	ERROR CODE AND DESCRIPTION.....	28
6.1.	ZERO CALIBRATION:	28
6.2.	SPAN CALIBRATION	28
7.	PRINT LABEL.....	29
7.1.	MINI PRINTER (BUILT-IN).....	29
7.2.	THERMO PRINTER (EXTERNAL PRINTER):	32
8.	APPLICATION EXAMPLE (II):	36
8.1.	EXEMPLAR 1 (SINGLE INTERVAL SETUP):.....	36
8.2.	EXEMPLAR 2 (DUAL INTERVAL SETUP):.....	36
8.3.	EXEMPLAR 3 (LINEARITY CORRECTION)	36
8.4.	FUNCTION DESCRIPTION	37
8.5.	PERIPHERAL APPLICATION	39

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/UWE/W22 operation manual.html](https://the-checkout-tech.com/manuals/UWE/W22%20operation%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)