



PERSONAL SCALE: FR-MS

(MS3200 Indicator, Product Type MS-3200)

FEATURES

1. Compact Dimensions: 220×90×40
2. **Material:** Aluminium
3. **Display Options:** LCD-display med 5 tecken
4. **Capacity/Division:**

TABELL 1

CAPACITY	DIVISION1	DIVISION 2	DIVISION 3
200 kg	0,05 kg	0,1 kg	0,2 kg

5. **Power:** Rechargeable battery 6×AA / AC adapter 9V 500mA
6. **Power saving:** auto shut-off timing selectable (120seconds/180seconds/240seconds/360seconds/Off)
7. **Operating Temperature:** 5 - 35°C
8. **Operating Humidity:** 25 % - 95 % RH

9. **4Keys:**
- | | |
|-------------|--------------------------------------|
| HOLD/BMI | UNIT/WEIGHT , ZERO , TARE |
| HOLD/BMI | Press this key to store weight value |
| UNIT/WEIGHT | Toggle among KG and LB unit |
| ZERO | Zero the weight |
| TARE | Tare the weight |

11. **Zero Range:** (4 % to full capacity)

12. **Tare Range:** (100 % to full capacity)

13. **Error Message indication:**
- | | |
|--------|------------------------------|
| EEEEEE | Overload |
| ErrL | Power on zero count too low |
| ErrH | Power on zero count too high |
| ErrE | Eeprom Error |
| ⊕-⊖ | Low battery indication |

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Vetek/FR-MS user manual.html](https://the-checkout-tech.com/manuals/Vetek/FR-MS%20user%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)