



## USER MANUAL

### Beam Scale WB 3ton/0,1kg



**Beam Scale for general weighing.**  
This is a simple and robust Scale for normal environmental. Not to be used in wet or aggressive applications. Very robust steel construction and easy to move. Lifting handles. Pillar for Indicator included.

- Weighing EU pallets, parcels, small tanks, containers and conveyors or anything.
- Free position of the beams
- Industrial design.
- Tare and Print function.
- Option: Printer
- Option: Battery supply
- Option: EC-Approval.
- Other models of Indicators e.g. for batching.

#### **Specification**

Dimension:	2 pcs 1210 x 100 mm. Height 95 mm.
Surface:	Painted, IP67
Capacity:	3000 kg
Graduation:	100 g (other to be specified before delivery)
Weight:	Totally 30 kg.
Power:	230 VAC / 9 VDC adaptor included.
Display:	6 digits 19 mm LCD with backlight.
Output:	RS232
Cable:	4,5 m

#### **Installation**

1. Adjust the feet on the beams so the beams stand steady. Check that nothing other than the feet takes load
2. Connect 230 VAC adaptor and both cables from the beams.
3. Push ON. Ready!

#### **INTRODUKTION**

TI-1200-S Digital Indicator is a general purpose, industrial grade weight indicator. Normally it comes calibrated 3000 kg / 0,1 kg

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*