


Model 402

AGRICULTURAL SCALE

Operator's Manual



FAIRMONT, MINNESOTA 56031

U.S.A.

PHONE 507-238-4461

TABLE OF CONTENTS

	<u>Page</u>
GENERAL	1
SCOPE OF MANUAL	1
DESCRIPTION.....	1
SPECIFICATIONS	2
INSTALLATION	3
UNPACKING INSTRUCTIONS	3
SIGNAL CONNECTIONS.....	3
ALARM OPTION CONNECTIONS	3
BCD INTERFACE CONNECTIONS	3
AC POWER CONNECTION.....	4
DC POWER CONNECTION.....	4
COARSE ZERO ADJUSTMENT.....	4
OPERATING INSTRUCTIONS	5
FRONT PANEL CONTROLS AND DISPLAY	5
REAR PANEL CONTROLS AND CONNECTIONS	6
POWER UP PROCEDURE.....	7
LAMP TEST	7
GROSS WEIGHING	7
NET WEIGHING (WITH ANALOG TARE OPTION).....	7
NET WEIGHING (WITH PUSHBUTTON TARE OPTION).....	7
OPERATING THE ALARM OPTION	7
OPERATOR TROUBLESHOOTING GUIDE.....	8
WARRANTY AND SERVICE POLICY	9

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <https://the-checkout-tech.com/estore/catalog/>

We also offer some free downloads, a free keyboard and keysheet layout designer,
cable diagrams and free help and support.

<https://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*