



WEIGH-TRONIX

SCALES FOR AGRIBUSINESS



Model 915 Indicator Service Manual

Table of Contents

| | |
|---|----|
| Programming | 5 |
| The Hidden E Key | 5 |
| 915 Configuration Menu | 6 |
| Configuration Mode | 6 |
| Viewing Current Configuration Code | 7 |
| Entering A New Configuration Code | 7 |
| Calibration Diameter | 8 |
| Using Table 1: Configuration Code Example | 8 |
| Table 1: Configuration Code Chart | 9 |
| Table 2: Valid Numbers For Configuration | 10 |
| Table 3: Model 915 Calibration Table | 10 |
| Configuring Custom Sensitivity With Capacity x Increment Size | 11 |
| Table 4: Row Numbers For Custom Capacity x Increment Size | 12 |
| Setting Custom Sensitivity and Capacity Row Numbers | 12 |
| Setting Custom Capacity Level | 13 |
| Calibration Mode | 14 |
| Calibrating Using A Known Weight | 14 |
| Getting Ready To Calibrate With BLH Model 625 Calibrator | 15 |
| Table 5: Calibrator Connections And Calibration Tables | 15 |
| Calibrating With A BLH Model 625 Calibrator | 15 |
| Internal Raw Counts Mode | 17 |
| Viewing Internal Raw Counts Display | 17 |
| Auto Zero Tracking Selection | 18 |
| Setting Motion Stability Window | 19 |
| Setting Filter Selection | 20 |
| Setting Update Selection | 20 |
| Configuring Input 1 and Input 2 | 21 |
| Setting Serial Functions | 22 |
| Baud Rate | 22 |
| Busy Display | 22 |
| Auto Print | 23 |
| Enquire | 24 |
| Layout | 24 |
| ASCII | 25 |

Pages are numbered consecutively beginning with the cover page.

| | |
|--|-------|
| Table 6 ASCII Control Codes | 27 |
| Printing Out the Configuration Parameters | 28 |
| Circuit Descriptions | 29 |
| Power Supply | 29 |
| Analog to Digital Circuitry | 30 |
| Microprocessor Circuitry | 31 |
| Display Card Circuitry | 32 |
| RS-232 Serial Circuitry | 32 |
| Optional RS-232 or Remote Circuitry | 32 |
| To Install Remote Receiver | 32 |
| Model 915 Master Reset | 33 |
| Programming Appendix | 34 |
| Configuration For Eaton, D-Star, and Two Additional Weigh-Tronix Menus | 34 |
| Table 7: Eaton: A Sample Set of Configuration Choices | 35 |
| Table 8: D-Star: A Sample Set of Configuration Choices | 36 |
| Table 9: Eaton Configuration Code Chart | 37 |
| Table 10: D-Star Configuration Code Chart | 39 |
| Technical Illustrations | 41-53 |

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*